



How to install a printer driver


1. Click 'Control Panel'




2. Click 'Printers'




3. Click 'Add a Printer'




4. Choose a local or network printer




5. Select a printer port and Click 'Next'




6. Click 'Have Disk'




7. Click 'Browse...'




8. Select a *.inf file in the extracted driver folder and Click 'Open'




9. Click 'OK'



10. Click 'Next'




11. Click 'Next'



12. Click 'Install this driver software anyway'



13. Click 'Next'



14. Click 'Finish'

